

## GENERAL

Owner has selected the EarthCam [Mobile StreamCam Robotic](#) (interior) system on their projects.

Contractor to purchase services direct from EarthCam.

EarthCam (System Vendor) will consult on and provide recommendations for optimal camera placement. Contractor will mount on stand in order to provide a full view of the desired work areas.

The Contractor shall supply at the camera locations a dedicated, non-switched, 15Amp 120VAC circuit in the form of a securely covered rated outlet.

The Contractor shall provide all maintenance, including cleaning of the camera, throughout the life of the project and make appropriate arrangements for the cameras to remain in operation continuously up to and through finalization of all structural, finishing work, furniture placement and “completed state” conditions necessary for documentation. For maximum efficiency of the time-lapse process Contractor will be required to relocate cameras throughout the project in order to continue capturing the construction phases as they progress.

At the conclusion of the project, Contractor will facilitate the removal and return shipping of the system using original shipping packaging and call tag provided by System Vendor. Instructions for return shipping will be provided by the System Vendor.

## SYSTEM VENDOR EXECUTION OPTIONS

The Contractor shall supply all equipment required for safe and secure access to the camera location for installation and maintenance, including access, lift or ladders and scaffolding.

The System Vendor may provide professional installation and removal services as an option to the Contractor.

**Vendor of choice:** EarthCam, Inc.

1-800-327-8422 [www.earthcam.net/contact](http://www.earthcam.net/contact)

**Exec Team:** +1-201-488-1111

[execteam@earthcam.com](mailto:execteam@earthcam.com)



\* 01 32 36 represents CSI Masterformat Construction Progress Video Monitoring and Documentation section number